





HP LaserJet Enterprise M750 Series Printer




Print the first or last page on different paper with Windows


1. On the **File** menu in the software program, click **Print**.




2. Select the product, and then click the **Properties** or **Preferences** button.




3. Click the **Paper/Quality** tab.




- In the **Special pages** area, click the **Print pages on different paper** option, and then click the **Settings** button.




- In the **Pages in document** area, select either the **First** or **Last** option.



- Select the correct options from the **Paper source** and **Paper type** drop-down lists. Click the **Add** button.



7. If you are printing *both* the first and last pages on different paper, repeat steps 5 and 6, selecting the options for the other page.



8. Click the **OK** button.

