




HP Color LaserJet Enterprise CP4020-CP4520 Series Printer




Create a stored job with Windows


1. On the **File** menu in the software program, click **Print**.



2. Select the product, and then click the **Properties** or **Preferences** button.



3. Click the **Job Storage** tab.



4. Select a **Job Storage Mode** option.

