







HP Color LaserJet Enterprise CP4020-CP4520 Series Printer



Paper orientation for loading Tray 2 or optional Trays 3, 4, and 5

Paper type	Image orientation	Duplex mode	How to load paper
Preprinted or letterhead	Portrait	1-sided printing	Face up Top edge at the left side of the tray 
		Automatic 2-sided printing	Face down Top edge at the left side of the tray 
	Landscape	1-sided printing	Face up Top edge toward the back of the product 
		Automatic 2-sided printing	Face down Top edge toward the back of the product 
Prepunched	Portrait or landscape	1- or 2-sided printing	Holes toward the back of the product 