




HP LaserJet Enterprise CP5520 Series Printer



Open the printer driver with Windows

1. On the **File** menu in the software program, click **Print**.



2. Select the product, and then click the **Properties** or **Preferences** button.

