


Clear paper jams in the High-volume finisher

Clear jams in the High-volume finisher output area

1. Open the top cover.



2. Lift the TF feeder, and then turn the knob while the TF feeder is lifted.



3. Remove any jammed paper.