




# LASERJET PRO 400 M401 PRINTER SERIES



## Automatically print on both sides (Mac OS X)

 **NOTE:** This section applies to the HP LaserJet Pro 400 M401d Printer, HP LaserJet Pro 400 M401dn Printer, and HP LaserJet Pro 400 M401dw Printer models only.

---

1. Insert enough paper into one of the trays to accommodate the print job.
2. On the **File** menu, click the **Print** option.
3. In the **Printer** drop-down list, select this product.
4. Select the **Layout** drop-down item.
5. From the **Two-Sided** drop-down list, select a binding option.
6. Click the **Print** button.