





RM2-6800-000CN

J8J87-67901

J8J88-67901



Lea esto primero

www.hp.com/support/ljM607

www.hp.com/support/ljM608

www.hp.com/support/ljM609

www.hp.com/support/ljM631MFP



www.hp.com/support/ljM632MFP

www.hp.com/support/ljM633MFP





J8J63-90921


1




2




3




4




5




6




7




8



9



10



11

