



HP LaserJet Enterprise 700 color MFP M775




Staples (stapling models only)

Item	Description	Part number
Staple cartridge	Each cartridge holds 5,000 unformed staples.	C8091A


For more information, go to www.hp.com/go/learnaboutsupplies.

Load staples


1. Open the upper-right door.



2. Pull the staple cartridge up and out to remove it.



3. Insert the new staple cartridge into the opening. Press down on the top of the staple cartridge until it clicks into place.



4. Close the upper-right door.

